









|   | OD Collar | Metal   | Composite  | Heavy Duty  |
|---|-----------|---|--|---|
| Diesel Pro®<br>Shop Pro ST              | 5 inches  | 232007DAV   | 232002DAV  | 243030DAV   |
|   |           |  |  |  |
| Fuel Pro®<br>380 Series                 | 6 inches  | 380134DAV   | 382002DAV  | 382152DAV   |
|   |           |  |  |  |
| Fuel Pro®<br>480 Series<br>Shop Pro FXP | 8 inches  | 482017DAV   | N/A  | 488001DAV   |
|   |           |  |  |  |

**Tightening the collar with the wrench:**

Simultaneously apply downward pressure to the top of the clear cover until it is seated on the body of the Fuel Pro/ Diesel Pro and hand tighten the collar until it no longer spins freely. Torque the cover assembly by rotating the collar clockwise three additional ribs using the collar wrench.